

HMMWV...

# An Unsticky Situation



The self-stick backing on the insulation liner in M966, M1025, M1026, M1036, M1045, and M1046 armored carriers doesn't always do its job. It turns loose and lets the headliner droop.

Eyeball the inside roof to see if the liner has any loose spots. Glue it back with primer coating, NSN 8010-01-040-0947. Hold the liner against the roof for about 3 minutes while the primer dries.

The NSN's for the four sections of liner are not listed in TM 9-2320-289-20P.

## Here they are:

Liner	NSN
Left Front	2590-01-205-2506
Left Back	2510-01-205-2507
Right Front	2510-01-203-9873
Right Back	2510-01-203-9872

Before you install the liner, spray primer coating on the roof to make sure the liner stays put.

