

Wheeled Vehicles ...

Insulation Installation

You operators who are lucky enough to drive vehicles that have cab insulation don't like to hear that you can't have it anymore.

But that's what happens when your mechanics say they can't find an adhesive that'll hold the stuff in place.

There's no need for that problem. If an adhesive is not specified in your vehicle's repair or parts TMs, your mechanic can use spray adhesive, NSN 8040-00-181-7761.

Clean the mounting surface of all old insulation and adhesive using a scraper and dry cleaning solvent, NSN 6850-00-281-1985. Then spray the adhesive

Remove old adhesive
with dry cleaning solvent



on the insulation and the mounting surface.

Apply the insulation to the surface and press it into place and hold it for about 15 seconds to allow sticking.

Then remember next time to keep the water hose away from the cab interior. Moisture in the cab is no good for electrical connections or insulation.

HOW'S MY
CAB INSULATION
REPLACEMENT
GOING?

GREAT! NOW
THAT I'VE GOT
THIS NEW SPRAY
ADHESIVE!