

FMTV...

Add Convex Mirrors

GET A BETTER VIEW OF WHAT'S ALONGSIDE YOUR FMTV, DRIVERS, BY HAVING YOUR MECHANIC INSTALL CONVEX MIRRORS ON THE REAR VIEW MIRROR MOUNTS.

NOTE THAT ONE BRACKET MUST BE ORDERED DIFFERENTLY.

TO GET THE DRIVER'S SIDE BRACKET, ORDER BY PART NUMBER 915920 ON A DD FORM 1348-6 USING CAGE 28116 AND RIC 59C.

Bracket,
NSN 5340-01-
479-0602

Bracket,
PN 915920



FMTV Woodland Camo Covers

If your FMTVs are getting woodland camouflage paint jobs, you'll be needing one of these woodland camouflage cargo covers:

2 ½-ton cargo—NSN 2540-01-385-9462

5-ton cargo—NSN 2540-01-386-2952

5-ton cargo (long wheelbase)—NSN 2540-01-387-5734

5-ton dump—NSN 2540-01-420-5985

M35A3 Alternator Bracket

NSN 5340-01-444-9149 gets the 2 ½-ton truck's alternator bracket. The NSN is missing from Item 12 in Fig 51 of TM 9-2320-386-24P.