

M917A1 Dump Truck...

# CHECK CLEARANCE AT BRAKE CHAMBERS

SHUT YER EYES, LENNY!  
WE'RE GONNA HIT!

BEEN NICE  
KNOWIN' YA,  
SQUIGGY!

Beep  
Beep  
Beep

If you're going to use your M917A1 dump truck in a paving operation with the 780T bituminous paving machine, you need to reposition both the right and left rear-rear axle brake chambers.

The chambers are located so low on the truck axle that the rollers of the paving machine make contact with them during paving. The resulting damage can leave you brakeless.

To move the chambers, eyeball the information found in TB 43-0001-62-5 (Apr 00) on Pages 3-4 through 3-10.

If you don't have a copy of the TB, ask your TACOM logistics assistance representative for help. Or you can ask ol' Half-Mast to send you a copy of the pages. He'll need your regular mailing address.

You can also access the information on the M915 Family of Vehicles web page at <http://www-acala1.ria.army.mil/DLCM/dsa/LCA/AF/M915>.

