

DON'T FORGET PUMP PM

THIS M17 CHECKS OUT... GUESS I'M DONE FOR THE DAY.

HEY! HEY! WHAT ABOUT ME!? PUMPS NEED PM, TOO!



YOUR M17 OR M12 DECON WILL RUN DRY IN THE FIELD IF YOU FORGET THESE PM POINTS FOR THE 65-GPM PUMP.



BEFORE YOU GO TO THE FIELD, CHECK **BOTH** THE INLET AND OUTLET HOSE CONNECTORS FOR GASKETS. IF A GASKET IS MISSING OR CRACKED, THE PUMP CAN'T BUILD UP ENOUGH PRESSURE TO PUMP WATER.

IN THE FIELD, DON'T FASTEN EITHER HOSE MORE THAN HAND-TIGHT. IF YOU OVERTIGHTEN EITHER HOSE, YOU'LL STRIP THE THREADS. THAT'S THE LAST TIME YOU'LL BE ABLE TO FASTEN THAT HOSE TIGHT.

Gasket missing or cracked?

YOUR REPAIRMAN CAN ORDER NEW GASKETS WITH PN 13230E5325 FROM SCHLEYER PUMP, (765) 643-3334.



Don't screw on hoses more than hand-tight