

# The Long and the Short of It



The bolt connecting the two engine mounting brackets, NSN 2510-00-570-9715 and NSN 2920-00-226-1984, together on your ammo carrier is a bit too long for its own good.

When installed as shown in Fig 2 of TM 9-2350-293-24P, the end of the bolt sticks up enough to rub against the starter housing.

Stop the rub by adding two extra washers, NSN 5310-00-809-8540, between the head of the bolt and the bottom of the resilient mount, NSN 5342-00-080-3496. Three washers take up the extra length and protect the starter housing.

