

# DON'T SLIP UP!



**H**ow fast you enter or exit the troop compartment of an M113-series personnel carrier can mean life or death on the battlefield. So it doesn't help if you go slipping and sliding down the ramp.

If the ramp's nonslip coating is worn, footing gets a little tricky. In wet weather, it's downright dangerous.

IF THE RAMP SURFACE ON YOUR CARRIER IS DOWN TO BARE METAL, FIX IT LIKE THIS...

1. Wash the surface thoroughly with soap and hot water. Use a nylon scrub brush to remove dirt, grease and loose paint. Rinse with hot water to further cut grease and oil.

2. Let the ramp dry completely.

3. Use a paint brush—such as NSN 8020-00-245-4516—to apply nonslip walkway compound to all the bare patches. NSN 8010-00-141-7838 gets a gallon of the olive drab walkway compound.

4. Allow the compound to dry for 24 hours before stepping on it.

Add nonslip walkway compound to bare spots

