

M2/M3-Series Bradleys, MLRS Carrier, M113-Series FOV...

Play the Angles

OUR TRACK IS
DOOMED...

...UNLESS
YOU LEARN...

...TO PLAY
THE *RIGHT*
ANGLE!

When assembling single pin track on your Bradley, MLRS or M113, you'd better play all the angles!

When assembling track on the ground, you've got to properly angle the shoe before inserting the pin. If you don't, the bushing will fail and you'll be back out there replacing track shoes.

Track looks "wavy" when shoes are joined at wrong angle



YOUR -10 TM HAS
SPECIFIC INFO ON
HOW TO PROPERLY
ASSEMBLE TRACK.

HERE'S THE
PROPER ANGLE
FOR YOUR
VEHICLE...

| Vehicle | Track | Angle |
|---------------------------|------------|-------|
| M113-series FOV | T130/T130E | 20° |
| M2/M3-series Bradley/MLRS | T157/T157I | 15° |