

PLS...

CAB INSULATION

YOUR PLS IS IN EXCELLENT CONDITION... AND I CAN'T EVEN FIGURE OUT HOW TO REPLACE MY INSULATION.



SEE?

HOW'D YOU DO IT?

HIRE A MAID?



NO, YOU JUST NEED TO WORK HARD AND IT HELPS TO KNOW THE NSNs. F'RINSTANCE, THE NSN FOR PLS CAB INSULATION IS 2510-01-511-5603.



Dear MSG Half-Mast,

The cab insulation inside our unit's M1074 palletized loading system is looking pretty shabby.

Is there an NSN for the insulation?

SGT C.D.

Dear SGT C.D.,

Order the PLS cab insulation with NSN 2510-01-511-5603.

This NSN gets a 60-ft roll of polyester foam that's one-half inch thick and 54 inches wide. Para 17-19 of TM 9-2320-364-20-5 has the lowdown on replacing the insulation. These instructions have the measurements you need for each piece of insulation.

Make a note of the NSN until it's added to Page BULK-2 of the -24P.

Half-Mast