

M16-Series
Rifle,
M4/M4A1
Carbine...

HOW DO YOU MOUNT M68 SIGHT?



HEY! WATCH
WHERE YOU
PUT THAT!!

Dear Half-Mast,
How do you mount
the M68 reflex sight
on the M16 rifle and
M4 carbine?

SGT F.S.



SERGEANT F.S.,
IT DEPENDS ON WHAT
VERSION OF THE M16
YOU HAVE.

For mounting the M68 on an M16A2, you need a mount, NSN 1240-01-410-7427, which should be assembled with short machine screws, NSN 5306-01-442-2407. But for the M4/M4A1 carbine and M16A4 rifle, you also need a spacer, NSN 5365-01-448-8912, and different machine screws, NSN 5305-01-448-9826. See WP 0019 00-2 through 0020 00-3 in the M68's TM 9-1240-413-12&P for more details. The mount comes with the spacer and both types of screws.

NSN 1240-01-410-7427 brings
mount and hardware for M68

