

Tie It Down and Moor-It!



Make sure your birds are properly secured to the ground so they won't fly away on their own when high winds kick up.

First, check out your -23 TMs for typical blade tie-down instructions and aircraft mooring procedures.

Second, check out TM 1-1500-250-23, *Aviation Unit and Aviation Intermediate Maintenance for General Tie-Down and Mooring On All Aviation Army models AH-64, UH-60, UH-1, AH-1, AND OH-58 Helicopters*. It gives procedures and hardware to keep birds anchored in heavy winds.

If there are any conflicts between the TM and the tie-down manual, the TM takes precedence.