

SINGGARS...

INSTALLATION KITS AT YOUR FINGERTIPS

THERE ARE MORE THAN 200 INSTALLATION KITS FOR INSTALLING SINGGARS IN WHEELED AND TRACKED VEHICLES.

EACH KIT HAS ITS *OWN* COMPONENTS LISTED IN ITS *OWN* TB.

THERE ARE FOUR INSTALLATION KITS USED IN HMMWVS. HERE THEY ARE...

Radio	Kit	NSN 5895-01-	TB 11-5820-890-20-
AN/VRC-87/88/90	MK-2325/VRC	225-0510	27
AN/VRC-89/91/92	MK-2326/VRC	225-3332	28
AN/VRC-89/91/92	MK-2327/VRC	229-1285	29
AN/VRC-87/88/90 and AN/VRC-89/91/92	MK-2328/VRC	297-8000	90

THE MK-2327/VRC AND THE MK-2328/VRC ARE INSTALLED ONLY IN THE M998 AND M1038 HMMWVS WITH SOFT TOPS.

IT'S IMPORTANT TO MATCH THE VEHICLE, KIT AND TB *BEFORE* YOU BEGIN INSTALLATION.

ONE AREA OF CONFUSION IS WITH THE CABLES.

CABLES ARE BEING STORED TOGETHER AND LOSING THEIR SPECIFIC KIT IDENTITY.

THIS LEADS TO THE WRONG CABLE BEING USED.

IF YOU'RE DOING AN INSTALLATION WHERE THE CABLE CONNECTOR DOESN'T FIT QUITE RIGHT OR THE CABLE IS TOO LONG OR TOO SHORT, CHANCES ARE YOU HAVE THE WRONG CABLE!



HERE ARE THE CABLES FOR EACH KIT...



Cable	NSN 5995-01-	Length (ft)	Qty
MK-2325/VRC			
CG-3855/VRC	219-7035	18	1
CX-13302/VRC	274-5084	6	1
MK-2326/VRC			
CG-3855/VRC	219-7035	18	1
CG-3855/VRC	225-1660	21	1
CX-13292/VRC	219-4704	6	2
CX-13302/VRC	274-5084	6	1
MK-2327/VRC			
CG-3855/VRC	219-7035	18	2
CG-3855/VRC	219-7034	15	1
CG-3855/VRC	225-1660	21	1
CX-13292/VRC	259-9283	8	4
CX-13302/VRC	274-5084	6	2
MK-2328/VRC			
CG-3855/VRC	219-7035	18	2
CG-3855/VRC	225-1660	21	1
CX-13302/VRC	274-5084	6	2
CX-13292/VRC	259-9283	8	2

ONE MORE THING ABOUT THE CABLES—THEY WEAR OUT!

CHECK THE CABLES FOR OBVIOUS WEAR AND TEAR AND IF YOU FIND ANY, REPLACE THEM.

A GOOD CABLE SHOULD HAVE LESS THAN 1 WATT OF LOSS FROM END TO END.

SOME RECENTLY CHECKED CABLES THAT WERE INSTALLED AND BEING USED HAD AN 8 WATT LOSS!

THAT KIND OF LOSS COULD CUT THE DISTANCE OF YOUR CONVERSATION IN HALF.

