



- Find the hole or tear on the **inside** of the fabric. Make all repairs on this side.
- Brush off loose soil or dirt from the area to be taped. Clean the area with an alcohol pad. Wipe a large enough surface so that the tape will fit well inside the cleaned area.



- Let the fabric dry.
- Spread the fabric on a flat surface.
- Cut the tape 2 inches longer than the hole you want to cover.
- Using the scissors, round off the four corners of the tape. Rounded corners make the tape less likely to peel off.
- Peel off the film liner from the tape as you apply the tape to the inside of the fabric.
- Press the tape firmly against the fabric. Allow the tape to set. The longer the better. Overnight is best, but give it at least 20 to 30 minutes.

Tentage Repair Kit

You can also mend vinyl-coated fabrics by using the updated tentage repair kit, NSN 8340-00-262-5767. The canvas sheets that originally came with the kit are no longer available. The Army has replaced them with 60-in polyester sheets for field repairs. They come in both green and tan. If you don't need the entire kit, order the sheets separately:

Sheet color	NSN 8305-01-238-
Green	0342
Tan	8076

The kit also comes with adhesive for applying polyester patches.



Mechanic's Coveralls in Universal Camo

You can now order mechanic's coveralls in universal camouflage. Here are the NSNs:

Order them through the DoD EMALL website:
<http://www.dlis.dla.mil/emall.asp>

NSN 8415-01-534-	Size
7375	Small
7376	Medium
7377	Large
7383	X-large
7387	XX-large