

GET THE RIGHT TRANSMISSION FLUID

TO GET THE RIGHT TRANSMISSION FLUID, TES-295, FOR THE MRAP RG31 FOVs USE THESE NSNs...

NSN 9150-01-	Quantity
552-9119	1 qt
565-0981	Six 1-gal containers
552-9157	5-gal container
551-2796	55-gal drum

LISTEN UP. DO **NOT** MIX OTHER TYPES OF FLUIDS, LIKE DEXRON III OR VI, IN THE RG31'S TRANSMISSION.

THAT CAUSES UNNECESSARY WEAR-AND-TEAR AND PERFORMANCE PROBLEMS.



IF YOU'VE USED THE WRONG TRANSMISSION FLUID IN AN MRAP RG31 VEHICLE, DRAIN IT!

REFILL IT WITH TES-295 FLUID.

ALSO, MAKE SURE YOU REPLACE THE TRANSMISSION FLUID'S FILTERS, NSN 2910-01-508-1913 AND 4330-01-520-4832, BEFORE YOU REFILL THE TRANSMISSION.