

HYEX...

WALK THE
HOSES BACK.
DON'T YANK 'EM!

Don't Yank the Hoses!

Come on, operators! Go easy on the excavator's hydraulic hoses for tool attachments when pulling them away from or bringing them back to the vehicle.

That means you don't yank on the hoses or let them snap back into the recoil spool. Sooner or later, this yo-yo treatment will break the spring inside the recoil spool. Then you can't rewind the hoses.

To make the hoses and recoil spool last longer, slow and easy is the way to go.

M400W Skid
Loader...

CRAWLER TRACK REMINDER

Operators, these new skid loaders are real workhorses for loading and carrying material at the work site.

If you haven't noticed already, the vehicle's steel crawler track gives you extra traction when operating in sand, dirt and snow. Just remember to remove the track when you drive the skid loader on concrete, asphalt or black-topped hard surfaces. If you don't, the track's steel edges will chew up and damage these surfaces. Also, it causes unnecessary wear-and-tear to the vehicle's tires and hydrostatic-drive train.

TAKE THE STEEL
CRAWLER TRACK
OFF WHEN
OPERATING ON
CONCRETE OR
ASPHALT.

THAT SAVES
WEAR AND
TEAR ON THE
TIRES AND
DRIVE TRAIN.