



Bar Makes Track Connecting Simple

Few things are more frustrating than trying to reconnect broken track or install new track on your Bradley and not being able to line up the bushing holes just right.

If you don't line up the bushing holes just so, good luck trying to slide in the connecting pin. Even using the track connector seldom makes the task any easier.

But don't give in to temptation and break out the sledgehammer to bang in the pin. That may help work out your frustrations, but it causes damage to the pin and bushings. That'll eventually result in track failure.

A much better tool is a tanker's bar. Just wedge the end of the bar between the two shoes and pull up and down to manipulate the bushings until they line up. Then the pin slides in easily. Be sure to follow the track alignment procedures outlined in the -10 TM.

