

HMMWV...

## FUEL TANK ACCESS COVER




**A** cargo floor access hole and cover kit, NSN 2510-01-454-7077, lets you work on a HMMWV fuel tank without dropping it.

Once the kit is installed, you can work on the sending unit or replace a leaking access cover gasket with the fuel tank in place.

The kit comes with instructions, hardware and plate. Get the kit and the next time you have to drop the tank, make the hole and install the cover while the tank's off.

The kit cannot be used on ambulances (M996/M997) or Avengers because of their design. The kit might prove impractical on shelter carriers, too.



## FMTV D-rings Get Lube

It's a simple thing, maintainers, but don't overlook the cargo bed D-rings on FMTV trucks and trailers when you're lubing. LOs require the D-rings be lubed by oil can every 1,000 miles or monthly. If you ignore the lube, you'll have problems with corroded or broken D-rings—and your hauling will come to a halt.