



Finding Your Way



If the floating dial on your new lensatic compass, NSN 6605-01-196-6971, is not floating, don't turn in the compass until you try lifting the eyepiece.

The eyepiece locks the dial down to keep it from being damaged when it's not in use. If you don't lift the eyepiece, the floating dial won't work. It has to float for the needle to show north.

That tip and others are on the card with use and care instructions that comes with every new compass. If your card is lost, contact James Boyd at CECOM, DSN 992-9511 or (732) 532-9511. His e-mail is: boydj@mail1.mommouth.army.mil



He will send you a new card. FM 21-26, *Map Reading and Land Navigation*, also has this info.

The old compasses, NSN 6605-00-151-5337 or NSN 6605-00-846-7618, are unserviceable and have been condemned for leaking the radioactive material that made them glow. Turn them in to your local Radiation Safety Officer per AR 11-9 and get the new compass.

The condemned compasses were made by Stocker and Yale. Commenga makes the new one.