


A Little Oil's OK

When you operators drain the coalescing filter as part of the weekly PMCS for the compressed air system on the HET and PLS tractor trucks, you'll see a combination of **oil** and water run out.

No problem. The filter is there to remove oil and water before the air goes to the dryers and reservoirs.

Operator PMCS for the PLS already says that a small amount of oil coming from the drain is normal, but a steady stream is not. Report that to your mechanics.

This same PMCS holds for the M1070, although it's not currently in the TM. It'll be added at the next change or revision.



Storage Box Replacement

Need to replace one or more of the storage boxes on your M871-series semitrailers? You've got two choices:

- Contact Dynaweld Inc, 406 N Highland Rd, Aurora, IL 60506, phone (708) 896-0009. Dynaweld may have storage boxes on-hand.
- Fabricate the boxes using 12-gauge sheet steel, NSN 9515-00-237-1890. That'll get you a 4x8-ft sheet, from which you can make boxes using the dimensions from the old ones. The hardware to attach the boxes is shown in Fig 33, TM 9-2330-386-14&P.

