

GIVE WATER THE HEAVE-HO

Water from hoses and rain has a way of getting inside the line replaceable unit (LRU) boxes on your MLRS. When that happens, the fire control system shorts out and you can't fire.

So keep your MLRS combat ready with this diligent preventive maintenance:

↳ Never use high-pressure water above the tracks.

↳ Cover LRU boxes with plastic when cleaning the rest of the hull.

Cover LRUs with plastic before cleaning



↳ If your MLRS will be sitting for long periods, open the hull drain plugs. That lets rainwater drain out as fast as it enters the vehicle.

↳ Whenever possible, park your MLRS on a slight incline with the rear of the vehicle a bit lower than the front. That helps water drain out quickly.

↳ Keep the cab and fire control system covered with a tarp to keep out rainwater. NSN 2540-00-587-2532 brings a 12x17-ft waterproof tarp.

SOMEHOW I THINK A TARP MIGHT GIVE ME A LITTLE MORE PROTECTION.



Use tarp, NSN 2540-00-587-2532, to keep vehicle dry

