


HMMWV...

Disconnect Both Neg Cables



Mechanics, before you start work on the electrical system of M998A2-series HMMWVs and the M1113/M1114/ M1123 vehicles in the family, completely disconnect the batteries.

These vehicles have a dual voltage system. That means disconnecting **both** negative battery cables, not just one. If you attempt electrical system work with even one negative cable still connected, you risk component damage and severe shock.

So disconnect the system using the info found in Para 4-73b, TM 9-2320-280-20-2, for the M998A2-series and M1123 trucks, and in Para 4-68b, TM 9-2320-387-24-2, for the M1113/M1114 vehicles.

Full details are found in TACOM Maintenance Advisory Message (MAM)-00-012, *HMMWV 24-Volt Electrical System (Jun 00)*.