

ICE IS A BRAKE BUSTER



Mother Nature is kind of like a yo-yo. That is, the temperature goes up and down. One day it's warm, the next day it's cold.

A change in temperature means trouble is brewing if you don't drain your vehicle's air tanks, especially in warm weather. That's because moisture corrodes air lines, relief valves, safety valves and even the tank itself.

But frozen water (ice) in your vehicle's brake system is double trouble!

Water expands when it turns to ice. The pressure will burst most anything. You lose your brakes, control of your vehicle, maybe your life.

The solution is simple—after the day's run, no matter what the weather, drain the vehicle's air tanks.

