


FIRMLY CONNECT QUICK-DISCONNECT



When the tank's powerpack goes back into place, the main hydraulic pump gets reconnected.

Sounds easy as 1, 2 and 3. After all, the supply, return and case drain lines all have quick-disconnects that make the job simple and easy.

W-e-e-ll, it's a bit more complicated than that.

The case drain line sits back in a corner, so its quick-disconnect is hard to attach. Yet a loose connection will cause an increase in hydraulic pressure and temperature that could ruin the hydraulic pump.

So make sure the quick-disconnect is firmly connected. Here's how:

After you attach the case drain line, grab the elbow portion and give it a good upward pull. If the quick-disconnect is not attached properly, it'll pop free when you pull it up. If it pops free, try again. Keep repeating the procedure until the quick-disconnect is properly connected.

Case drain line pops loose if not attached properly

