



DOING PM
SHOULD BE
**SECOND
NATURE!**



MSE Tester

Use loop interface tester, NSN 6625-01-448-8798, to take the guesswork out of connecting to circuit and packet loops of the MSE system. This hand-held, battery-operated tester can tell you where your problems are. For more information on the tester, contact the CECOM POC at DSN 992-8311 or (732) 532-8311. Or e-mail them at:

lorraine.foster@mail1.monmouth.army.mil

M1112 WATER TRAILER BEARINGS

The wheel bearing listed in TM 9-2330-397-14&P is for the bearing only. To get the race and outer bearing assembly, order NSN 3130-00-100-5997 (Fig 13, Item 25). The inner bearing and race assembly come with NSN 3130-00-100-5303 (Fig 13, Item 22).

FMTV Cargo Cover Repair Kit

NSN 2540-01-496-4442 gets a cargo cover repair kit for the FMTV 2½-ton and 5-ton trucks. This kit is used for minor repairs only. Instructions come with the kit.

M989 HEMAT SLACK ADJUSTER NSN

Use NSN 2530-01-489-0369 to get the rear slack adjuster for the ammunition trailer's mechanical brake system. The NSN shown as the first Item 1, Fig 9 of TM 9-2330-383-14&P, gets the wrong part.

MICRO RAPPEL LIMIT CHANGE

The care and use pamphlet that comes with the micro rappel system, NSN 4240-01-498-8810, limits the number of rappels to 10 before the rope has to be replaced. Actually, the rope can handle up to 50 rappels. After that, use NSN 4020-01-498-8553 for an 82-ft replacement rope. NSN 4020-01-498-9109 gets a 660-ft rope that can be cut into 8 separate 82-ft lengths.

AB-1339/G Antenna Covers

MSE units, masthead caps, NSN 5340-01-270-5083, keep the weather and the dirt out of mastheads when the AB-1339/G antenna is stored on trailers. Use them.

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 340312, requirements for TB 43-PS-Series.

Would You Stake Your Life ^{right now} on the Condition of Your Equipment?