



- Cover the air intake, radiator and cab with a tarpaulin when the vehicle will not be used for a while.




- Park the vehicle with the front facing away from the wind.



HEMTT...

## REMOVE ETHER CARTRIDGE



The hot and humid days of summer means it's time to remove the HEMTT's ether cartridge.

Summer weather causes the cartridge to rust and leak. Then the vehicle's ether start won't kick in when you need it for those winter months down the road.

So do your HEMTT a favor. Remove the cartridge in the summer or in places where it's warm all year around. The cartridge is there only to help the truck start in cold temps.

Just unscrew the cartridge from the solenoid valve and plug the hole with the cap that is chained to the solenoid.

Be sure to store the ether cartridge in a cool, dry place so it can be put back on when you need it—in cold weather.