

DON'T CUT THAT FUEL HOSE!



A leaking fuel hose on your 3-KW tactical quiet generator (NSNs 6115-01-285-3012; 6115-01-287-2431; 6115-01-322-8583; 6115-01-322-8582) can make for a real bad day. At the very least, you will have an environmental hazard—at the worst, a fire!

Holes are showing up in the fuel hoses because the pull/start rope of the recoil starter assembly is rubbing against the hose and cutting away some of the covering. This is happening between the primary fuel pump and the fuel filter assembly.

It seems the auxiliary fuel hose forces the primary fuel hose down into the pull/start rope. If you frequently start your generator manually, you will eventually cut a hole in the fuel hose.

Here's the fix:

1. Remove the auxiliary fuel hose before you manually start the generator.
2. After the generator starts, put the auxiliary fuel hose back in the same spot.
3. Check the primary fuel hose to make sure no rubbed spots are showing up. If your fuel hose is already cut or damaged, it must be replaced!

