


CLEAN AIR FOR CAB

SKOFF!
AHHHEE-UH... I NEED... SOME... ONE... TO...
SKOFF!

...CLEAN... THE... AIR... FILTER... ELEMENT...
SKOFF!



Filter elements for the cab's air system seem to get overlooked for regular cleanings. That's because they're located on the roof.

Regardless of how dirty the worksite conditions are, the filter elements keep clean air circulating inside the cab.

So before you clean the elements with low-pressure air (30 psi or less), check the air inlets for leaves, dirt build-up, and ice or snow.



Before the day's run, remove the element and tap it with your hand to get rid of trapped dirt. Do not bang it against the cab! You'll bend its sealing edge or crush filtering material.

