


LOUDSPEAKING PARTS!

IF YOU NEED TO INSTALL AN LS-671/VRC, NSN 5965-01-222-1420, THE SINGGARS LOUDSPEAKER, YOU'LL NEED **THESE PARTS** TO DO IT...

NSN	Item
5340-01-391-2740	Mounting plate
5306-00-225-9089	2 machine bolts (5/16-24 x 1 in)
5310-00-407-9566	2 lock washers, (5/16 in)
5310-00-081-4219	4 flat washers, (5/16 in)
5310-00-880-7746	2 hexagon nuts (5/16-24 in)



Halfway Is Not THE Way



Halfway is not enough when you unscrew the primary power cable from the LS-671 loudspeaker on your SINGGARS vehicular radio. It's all the way or nothing.

You need to unscrew the cable's connector the whole way before trying to unhook the cable. Some folks stop halfway. Then they yank and twist the cable in a vain effort to take it off. That just puts stress on the circuitry inside the J1 connector. If the circuitry gets damaged, no power gets through to the loudspeaker.

