

Stryker...

DON'T MAKE A SEATBELT SANDWICH



The driver's seat on your Stryker has a lot in common with a luxury sedan. It has two electronic switches—one for moving the seat forward and backward and another to move it up and down.

Just be careful when lowering the seat. The seatbelt receptacle on your left swivels to any position for extra comfort. If you're not careful, it can swivel all the way under the seat. When the seat goes down—**CRUNCH!**—you've made a seatbelt sandwich.

