

DEUCE...

NO STEERING WHILE DOZING!



Turning the wheel while dozing puts so much stress on the track that it can be thrown. Thrown track can crack road wheels, bend road arms and rip actuators from the hull.

And forget about sharp turns during other operations. You can throw a track that way, too.

If you have to make a turn while pushing a load, use the excavator's tilt cylinders, but not the steering wheel. That's hands off!

HYEX...

Walk the Hoses



Operators, easy does it when you “walk” the excavator’s hydraulic tool hoses away from or back to the vehicle.

Do not yank on the hoses or let them snap back into the recoil spool. Sooner or later this yo-yo treatment breaks the spring inside the recoil spool. Then you can’t rewind the hoses.

To make the hoses and recoil spool last longer, walk the hoses back—every time.