

# CAP INLET and OUTLET



If the M17-series decon's inlet and outlet assemblies are left open when the hoses are removed, dirt and sand get in the water pump and eventually destroy it.

Save the water pump by keeping the inlet and outlet capped when the hoses aren't connected. Order a 1 1/4-in quick-disconnect cap for the inlet with NSN 4730-00-485-5055. Order a 1-in quick-disconnect cap for the outlet with NSN 4730-00-929-0791. Keep the caps in the hose storage case when they're not installed.

If sand or dirt does freeze the water pump, run water from a hose through the outlet while you try to turn the water pump pulley back and forth by hand. That often will free the pump.

Cap inlet and outlet assemblies

