

When Air *Can't* Get Through



A clogged air filter element on your truck can be a real showstopper!

Moist air or snow sucked into the filter can freeze on the element. Once the element is coated with ice, air can't get through.

So, in damp, cold weather, keep an eye on your vehicle's air restriction indicator. On some vehicles, once the indicator shows red, the filter is plugged. On others, once a pointer reaches the red level on the indicator, the filter is plugged. Either way, get the element cleaned and dried out. Or get a new one.

Always keep snow cleared away from the air intake. In damp, cold weather it's a good idea to have a clean, dry element on hand for a quick switch.

