

Construction  
Equipment...

NO MATTER  
THE WEATHER...  
*DRAIN THE  
AIR TANK!!*



## AIR DRAIN REMINDER

**T**emperatures drop when the sun goes down. Nature puts the thermometer into a nosedive. The days may be warm, but the nights are cold!

A change in temperature means trouble is brewing if you don't drain your vehicle's air tanks. That's because moisture corrodes air lines, relief valves, safety valves and even the tank itself.

But frozen water (ice) in your vehicle's brake system is double trouble!

Water expands when it turns to ice. The pressure will burst most anything. You lose your brakes, control of your vehicle, maybe your life.

The solution is simple—after the day's run, no matter the weather, drain the vehicle's air tanks.

