


IT'S NOT OVER 'TIL IT'S OVER



After a mission, you're hot, tired, and ready to call it a day. But the job's not finished until you've completed your tank's after-operation PMCS.

That's especially important when it comes to servicing the main gun tube, bore evacuator, and breech. You should inspect, clean and service each item that's called out in the TM.

Why is this so important? Each of these checks are designed with **your** safety in mind. Something as small as a torn bore evacuator O-ring could result in a deadly flareback.

The main gun tube needs to be cleaned. The bore evacuator should be removed and the seals inspected. The breech needs to be disassembled and its parts inspected.

See Pages 2-104 and 2-105 in TM 9-2350-264-10-1 and Pages 2-94 and 2-95 in TMs 9-2350-288-10-1 and 9-2350-388-10-1 for the proper procedures.

