

# PAY ATTENTION!

WHOA! LOOKS LIKE YOUR RIFLE GOT TANGLED IN THE RAMP LOCKS!

HMMM... I WONDER IF IT'LL SHOOT AROUND CORNERS.



**S**oldiers, a short attention span is a dangerous thing when the ramp on a Stryker is opening or closing.

The cams inside the ramp locks are moving, so anything that gets in their way ends up mangled. That includes your fingers, a rifle barrel, and anything else accidentally stuck in the locks.

Also, the additional weight of slat armor sometimes means there's not enough pressure available to disengage the ramp locks. When that happens, you'll need to insert the manual control lever from the side of the lock into the cam and manually free each lock.

Those levers often come up missing. If that happens to you, order a new one with NSN 5340-21-914-6268. But **don't** try to disengage the cams with your fingers.

