

DON'T WIND AND GRIND

HEY!
STOP SLAMMING
THOSE GEARS
INTO REVERSE!!!



You've just pushed a load of debris out of the way and you and your dozer are heading back for more.

When you slammed the dozer's gears into reverse and moved out, you probably heard something that didn't sound right...the grinding noise of the transmission's gears!

It didn't sound right because every time you shift in or out of reverse without reducing speed you put unnecessary strain on your dozer's transmission. That's bound to shorten its life.

DON'T WIND
AND GRIND
'EM! INSTEAD,
KEEP THESE
POINTERS IN
MIND...



1. While your dozer's still on the move, push down the decelerator pedal. That slows down engine speed without changing the governor setting.
2. Stop your CAT dozer dead in its tracks.
3. Shift in or out of reverse.
4. Then ease up on the decelerator pedal to speed up the engine and return it to the governor control setting.

Decelerate
to shift
into or out
of reverse

