


# LIGHTS OUT



When working with the formation lights on your Chinook, it is not necessary to cut the wires to remove them or to gain access to other components. Formation light wires have quick disconnects and need no cutting.

So, the next time you're working with the formation lights, just unsnap the wires like it says in IETM 1-1520-240-23&P and don't cut them. The formation light wire connectors may not look like quick disconnects, but they are.

If you're not sure what to do, then call your senior mechanic before doing anything. Lights out in the barracks is OK, but lights out on your bird means NMC.

Unsnap quick disconnects instead of cutting wires

