

Disconnect *BEFORE* You Fold

OK, WE'RE DONE FOR THE DAY, LET'S FOLD THIS OPERATION UP.


REMEMBER, DISCONNECT BEFORE YOU FOLD MY GUN.

CREW CHIEFS AND MECHANICS, SAVE YOURSELF THE TROUBLE OF GUN POD REPAIR.

DISCONNECT YOUR KIOWA WARRIOR'S .50-CAL GUN UMBILICAL CABLE **BEFORE** FOLDING THE GUN!

The cable is simply not long enough to cover the added distance needed when folding up the universal weapon's pylon. When folding the pylon, the cable can bend or snap off the bracket welded to the gun pod.

To make matters worse, the umbilical cable is usually wrapped around the pylon mounting arm to keep it out of harm's way. But that just makes the cable even shorter!



THE SIMPLE SOLUTION IS TO DISCONNECT THE UMBILICAL CABLE FIRST, THEN FOLD THE GUN.

