



PARTS FOR MAINTENANCE STAND



Dear Sergeant Blade,

Recently a young soldier asked me how to take care of maintenance stands we have around the hangar. I told him to identify the stand by the NSN and locate what he needs. He came back to me stating he could not find any information.

I researched and found NSN 1730-00-269-8283 for the low-level maintenance platform. During my research, I found publications for several types of maintenance stands but nothing on the low-level stand.

Do you have any TM and repair part information?

SGT J. B.

Dear Sergeant J. B.,

Yes, we can help you with your maintenance stand parts. But when it comes to TMs, the stand was never supported and does not have a TM for maintenance. There's not much maintenance on the stand anyway.

However, you can order the parts you need with this information:

- Wheel assembly with universal brake, NSN 5340-01-340-8799
- Quick release pin, NSN 5340-00-935-8804
- Body catch clamp, CAGE 63422, PN 99-105-CO-BP1*
- Plate catch clamp, CAGE 63422, PN 99-106-CO-BP1*

*Order on a DD-Form 1348-6.

*Rotor
Blade*