


Pintle Needs PM, Too



DRIVERS, THE TOW PINTLE ON YOUR M88A1 RECOVERY VEHICLE COMES IN REAL HANDY WHEN YOU NEED TO TOW A DISABLED VEHICLE.



THAT'S WHY IT'S IMPORTANT TO KEEP THE TOW PINTLE LUBED REGULARLY.

IF YOU NEGLECT IT, THE PINTLE SEIZES UP AND WON'T OPEN WHEN YOU NEED IT.

SO LUBE THE PINTLE MONTHLY WITH GAA.

THERE ARE TWO LUBE POINTS THAT ARE EASY TO SPOT AND ONE THAT IS HIDDEN BEHIND THE PINTLE.

SO MAKE SURE YOU HIT ALL THREE WITH THE GREASE GUN.

