


M67 GLPS...


HEY, TURN OFF THE VEHICLE.

YOU WANT TO RUIN MY GYROS!?



TURN OFF VEHICLE FIRST!

POWERING UP THE M67 GUN LAYING AND POSITIONING SYSTEM (GLPS) CAN CAUSE COSTLY DAMAGE IF YOU DO IT WRONG.



PS 678

The GLPS can be powered up through its own battery power or by using its power adapter and connecting it to the vehicle power supply through the NATO plug.

However, many GLPS batteries have reached the end of their life and no longer charge properly. (If you charge a battery like it says in Section II of TM 9-6675-347-13&P and the battery shows a charge of less than 80 percent, the battery needs to go to maintenance.) So the only power choice then is vehicle power. And that's where the damage can occur.

The GLPS gyros are very sensitive to voltage spikes from the vehicle. The way to prevent these spikes is to first shut off the vehicle before you power up the GLPS. **And leave the vehicle off while the GLPS is on.**

WATCH PS FOR INFO ON ORDERING NEW GLPS BATTERY PACKS.

