


AUXILIARY FUEL PUMP ADVICE



If you're not using the auxiliary fuel pump on your 100-kW generator, make sure the auxiliary fuel switch on the electronic modular control panel is switched to OFF.



If the switch is left in the ON position, the fuel pump will run continuously and the pump will be damaged!

WHEN YOU'RE USING THE AUXILIARY FUEL PUMP TO TRANSFER FUEL TO YOUR GENERATOR'S FUEL TANK FOR PROLONGED GENERATOR USE, YOU **MUST** MAKE SURE...

- the pump is never operated unless it is connected to a fuel source.
- there is a constant supply of fuel in the auxiliary location, such as a 55-gal drum or a fuel bladder.
- the fuel pickup line is secured to the fuel source and cannot be knocked loose.

