



GET RID OF DEBRIS

YOU'VE GOT
ASPHALT BUILT UP
ON YOUR DRUM!

WHY DIDN'T THE
SPRAY NOZZLES
PREVENT THAT!



'CAUSE THE SPRAY
NOZZLES AREN'T
WORKING! YOU
DIDN'T **CLEAN ME**
AND THE **REST OF**
THE **SEDIMENT**
FILTERS!




THINK YOUR
VIBRATORY
ROLLER CAN DO A
GOOD COMPACTING
JOB WITH ASPHALT
CLINGING TO ITS
DRUM?

I'VE GOT
TWO WORDS TO
SAY TO YOU...
THINK
AGAIN!


Asphalt buildup is just what happens if you don't clean the sediment filters on both water tanks. The filters catch debris that can clog the spray nozzles. Clogged spray nozzles stop the water spray that stops asphalt from building up on the drum.

So, remove the sediment filters and clean the strainer element weekly. Make sure the shut-off valve is closed before removing the filter's housing. If you forget, you'll be the one getting sprayed!

Clean sediment filter weekly...



...to keep water nozzles spraying



Pull out the strainer element and flush it with clean water. Clean out the filter housing, too. Once the strainer is back in the filter housing and the filter is in place, open the shut-off valve.

Do the same thing for the roller's other water tank.