


# DEMYSTIFYING EMS-NEXT GEN SOFTWARE

ARE YOU  
BAFFLED BY  
YOUR HEMTT'S  
NEWEST  
SOFTWARE?

HERE'S THE  
SCOOP ON THE  
ELECTRONIC  
MAINTENANCE  
SYSTEM (EMS)-  
NEXT GEN (NG).

EMS-NG CONTAINS  
INTERACTIVE ELECTRONIC  
TECHNICAL MANUALS (IETMs)  
FOR VEHICLE PLATFORMS  
SUCH AS HEMTTs, PLS,  
FMTVs AND HMMVVs.



EMS-NG

EMS-NG IS THE *THIRD*  
VERSION OF EMS AND  
REPLACES EMS-2.

LIKE EARLIER VERSIONS,  
EMS-NG TROUBLESHOOTs  
VEHICLES AND PERFORMS  
DIAGNOSTICS TO HELP KEEP  
THOSE WHEELS TURNING.

BUT IT ALSO SPORTS  
THE FOLLOWING  
IMPROVEMENTS...

- You'll automatically receive important notices, bulletins and critical software updates.
- Parts ordering is fully automated, so now you can toss parts in a virtual shopping cart and go!
- EMG-NG IETMs can be run from the disk, a benefit to Soldiers in the field.

SUPPORTED OPERATING SYSTEMS AND MINIMUM SYSTEM REQUIREMENTS FOR THE EMS-NG VIEWER ARE...

- MS Windows 2000 Professional SP4 (512 MB RAM minimum)
- MS Windows XP Professional (512 MB RAM minimum)
- MS Windows Vista Enterprise (1 GB RAM minimum)
- RedHat Linux 5.3 (512 MB RAM minimum)
- CentOS Linux 5.3 (512 MB RAM minimum)
- 600 MHz processor or greater
- 1024 x 768 x 16-bit screen resolution
- 20 GB hard drive
- CD-ROM or DVD-ROM drive

ONE THING I PREDICT IS... EMS-NG AND THE OLDER EMS-2 CAN BOTH BE INSTALLED AND RUN ON THE SAME PC, LAPTOP OR MAINTENANCE SUPPORT DEVICE WITHOUT CONFLICT.



Versions 2.1.1. and older are compatible with Windows 2000, Windows XP, CentOS 4.6 and RedHat Enterprise 4.6.

Versions 2.1.2 and newer will work with Windows 2000, Windows XP, Windows Vista, CentOS 5.3 and RedHat Enterprise 5.3.


**Note:** Windows 7 OS is not currently supported.

EMS-NG Viewer Versions 2.1.1 and older can run on Windows Vista; however, after your administrator installs the EMS-NG Viewer on your PC, you will need to put Disk 3 (the IETM content) in your CD-ROM or DVD drive every time you want to access the TM data.

ARE YOU AN ADMINISTRATOR?  
READ THIS!



IF YOU'RE A USER,  
YOU NEED TO READ  
THIS!



If installation does not begin automatically after you insert the disk into a CD-ROM or DVD drive, choose **Start** in the Windows taskbar, then click **Run**. In the box that opens, type the following: [drive]:\setup.exe (but replace the word drive with the letter of your CD-ROM or DVD drive). Click **OK** or press **Enter** and follow the installation instructions on the screen.

You must also install the Autonomous Diagnostic Manager (ADM) software to perform diagnostic tests on a vehicle. The ADM software is usually distributed with the viewer and is the second disk in the folder.

If you need paper copies of an operator's manual and/or hand receipt, do the following:

From the opening screen, select a vehicle model.

Once inside the program, select **Help** from the menu selection at the top of the IETM.

Choose **About This TM**, and then click **Paper Copies of Operator's Manual** from the Table of Contents on the left. The hand receipt is a pdf link on this page and can also be accessed in the General Information Work Package under the Introduction section.

For EMS-NG support, contact the publication manager for your vehicle. The EMS team at TACOM also has an AKO page with more information. Visit the website:

<https://www.us.army.mil/suite/kc/5039212>

For follow-up EMS-NG support, call the manufacturer, O'Neil, at 1-800-413-6723 or email: [EMSupport@oneil.com](mailto:EMSupport@oneil.com)

