


HMMWV...


PM HELPS PIN BEAR UP

I KNOW HOW TO GET THESE BRUSH GUARD LOCKING PINS LOOSE!

WAITA-MINUT! ALL I NEED IS A LITTLE LUBE!



WITHOUT PM, ANYTHING MECHANICAL THAT'S CONSTANTLY EXPOSED TO WATER, DIRT, SAND AND MUD IS GOING TO GET A LITTLE ORNERY.



That's true of the retractable ball bearings on the HMMWV brush guard's quick-release pin, too. All that constant exposure to the elements eventually rusts the bearings in place.

Then you're stuck with a pin that won't release and a brush guard that can't be raised or lowered.

Keep the pin's bearings moving with a shot of lubricating spray, NSN 9150-00-458-0075, as required. Just give the ball bearings a squirt, then slide the pin in and out of the brush guard a few times to work in the lube.

