


Gage the Sprockets



Construction operations cause the drive sprocket teeth on your dozer to wear down. Over time, enough wear can let the dozer's track jump right off the sprocket!

So before the day's run, check your dozer's teeth. Use a drive sprocket gage to measure sprocket wear. Order a gage to measure the D5B's sprockets with PN 5P8616 and CAGE 11083 from RIC S9C on a DD Form 1348-6. NSN 5210-01-225-1132 gets a gage for the D7G and D8K dozers.

