


Annual Service Kits

YOU'LL WANT TO MAKE A NOTE OF THESE SERVICE KIT NSNs UNTIL THEY'RE ADDED TO THE HEMTT -A4 TECHNICAL MANUALS.



Model	NSN 4910-01-588-
M983A4, M985A4, M1977A4, M1120A4	1344
M978A4	1366
M983A4 LET	1407
M984A4	1415
M985A4 GMT	1421

These kits include all the replacement parts you need to perform the vehicle's annual service. For a list of the kit's components, send a request to:
donald.oconnor@us.army.mil

BEHOLD THE FOOTHOLD!



The foothold on the side doors of the armored security vehicle (ASV) is a handy place to step when you exit the vehicle. That is, as long as your boot doesn't get stuck in the foothold!

When you're ready to exit the ASV, place your foot on top of the foothold. Do not place your foot inside the "loop" of the hold. That way you won't get stuck, twist an ankle and land on your face! This also keeps Soldiers from falling on top of you or your getting in the way as they exit the vehicle.

Place boot on top of foothold

