


Safety Proofing Your Mount



HERE'S HOW TO SAFETY PROOF YOUR MOUNT SO THAT DOESN'T HAPPEN TO YOU...

- Lightly pull the quick-release pin to make sure it's secure in the universal pintle adapter. If the pin comes out, it's not secure. The pin can work out during firing, letting the mount come loose. Your armorer can order a new pin with NSN 5315-01-447-2233.
- Before firing, make sure the manual control handle that secures the mount cradle to the universal pintle adapter is actually locked. Sometimes it doesn't stay locked and the cradle works loose during firing. If it's not locked, tell your armorer. He needs to replace the handle.

Check quick-release pin for damage



Check that handle locks

Staying Out of a Jam

If you use the cartridge catch bag, empty it periodically during firing. If the bag becomes too full, your MK 19 could have trouble ejecting rounds. That could lead to stuck rounds and jamming.