

C'MON!
WE NEED
TO GET
GOING!

3 STEPS

to **BRAKE
RELEASE**

I'M
TRYING!

THE GEAR
SELECTOR
WON'T
MOVE!!



Having trouble getting your Bradley to shift into gear, drivers? Could be you haven't completely released the hand brake.


Releasing the hand brake for the TEC transmission may seem simple, but leave out a step and you're going nowhere fast. After all, the hand brake and gear selector are interlocked. That means if the hand brake isn't released, the gear selector won't move.

Release the hand brake like this:


1. Press down and hold the brake pedal.
2. Twist the knob on the hand brake handle and lift up.
3. Slide the handle **all the way forward** and down into the slot.

Step 3 is where the problem lies. If you don't slide the handle all the way forward and down, the brake is still applied and the gear selector won't move.

So if you've got a stuck gear selector, make the hand brake your first check.



Slide handle all the way forward and down to release brake



Handle left short will **not** release brake

