




STUCK LEVER LINKAGE REMINDER



To prevent these problems, wipe off the throttle linkage with a brush or clean rag. Then spray pivot points and connections with a shot of lubricating spray, NSN 9150-00-458-0075. Move the throttle lever back and forth a few times to work it in.



Make sure to spray the linkage at every scheduled service. Lube puts the slide and glide back into the linkage for smooth operation of the throttle.



Paint Shop Reminder

Before your dozer heads off to the paint shop, tape over the throttle linkage where it connects into the mounting bracket. That way the linkage won't get stuck "in place." Just make sure the tape is removed when the dozer comes back from the paint shop.